

ADRENALINE WORKSHOP

Proper Usage:



1

2

YOUR INSTA360 X4 CAMERA IS PLACED INTO / REMOVED FROM HOUSING FROM ONE SIDE ONLY (NON-LCD SIDE).

1. Insert camera into LoHawk housing until bottom of camera reaches corresponding inside limit of the housing.

2. Use your thumbs to press top of camera onto forward most edge of your LoHawk. Use your remaining fingers to aid in holding the mount in place as you insert the top of the camera into the housing.

To remove the camera from the LoHawk housing, reverse above steps so camera **EXITS** towards LOGO side of housing. This will take some effort the first few times; however, it will quickly become second-nature.



Mounting the LoHawk:



1. Measure

Determine mounting location. This will vary by personal preference depending on how far you need visor to open. The following are some examples based on the product pictures found in the LoHawk order page (distance to visor's edge):

- TFX: 60-110 mm
- G35: ~50 mm (@ front edge of skid plate)
- G3 / G4: ~55 mm

It's OK if you notice a small gap between your helmet's surface and the LoHawk's flexible mounting surface. This gap will not be there once the LoHawk is affixed to your helmet.



2. Clean

Clean your helmet's surface to ensure proper bonding with VHB tape.



3. Affix to helmet

1. REMOVE CAMERA from inside the housing before continuing on to next step.

2. Align and affix LoHawk to top of helmet... WITHOUT camera inside housing.

3. Apply even, firm downward pressure from within the housing for @ LEAST one minute.

4. Now, place your X4 camera into the housing (and repeat application of even, firm downward pressure for another full minute.

5. Allow a FULL 24 hrs for the adhesive's molecular bond to cure before using your LoHawk in a high speed environment.